


HP Media Center PC
Quick Setup
快速装配示意图

Copyright © 2004, 2005 Hewlett-Packard Development Company, L.P.
Printed in
www.hp.com

1 Keyboard and Mouse
键盘和鼠标



Wireless option

Refer to the setup instructions located in your mouse/receiver box.

无线装置

请参考鼠标/接收器包装盒中的安装说明。


OR
或者



2 Monitor
显示器

Refer to setup instructions that came with your monitor. Monitors may be sold separately.


请参考显示器附带的安装说明。显示器可能需要单独购买。




3 Speaker System
扬声器系统

Refer to the instructions that came with your monitor and speakers. Monitors and speakers may be sold separately.

请参考显示器和扬声器附带的安装说明。显示器和扬声器可能需要单独购买。




4 TV In
通过 TV In 将电视信号接入电脑



OR
或者

If you use a cable or satellite set-top box, pass the signal through the box.


如果您使用有线电视或卫星电视机顶盒，请通过机顶盒接入信号。



5 TV Out (TV connections are optional)
TV Out (电视连接是可选的)

TV signal from computer to TV

将电视信号从电脑接入电视




See the user documentation for TV display setup.
有关电视显示设置，请参考用户文档资料。

6 Remote Sensor
遥控器

Connect remote control receiver to computer.


将遥控器接收器连接到电脑。



OR
或者

If you use a cable or satellite set-top box, pass the signal through the remote sensor control cable.

如果您使用有线电视或卫星电视机顶盒，请通过遥控器控制电缆接入信号。



7 Remote Control
遥控器

Install AA batteries in remote control.
将两节 AA 电池装入遥控器。

